

CHRISTMAS DECAL DECORATIONS



Get
Fired
Up!

- 1) Glaze ornaments as desired using 2-3 coats of glaze and allow to dry.
- 2) Fire to recommended glaze temperature 1020°C to 1100°C (Cone 05 to Cone 04).
- 3) Cut out required decals and soak in water for a few minutes. Decal will slide easily off backing paper when ready.
- 4) Position decal on ornament, gently smoothing with finger or soft cloth.
- 5) To permanently fix decals low-fire as recommended. Schedule included.